Installation Procedure

WARNING

1.Switch off before installation.
2.Switch on only after complete installation and examination of the circuit.
3.Professional electrician for installation and maintenance only.





Downlight



Cutout (refer to cutout table)



IBSP221CT042	Cutout: Φ42mm
IBSP221CT042-PIN	Cutout: Φ42mm

1 2



Connect power supply

If the external flexible cable or ord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.





3 4

COMPLETE



The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.